





NUMERICAL LIST OF PARTS 300W104 MACHINE

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
1517(803)	Presser Bar Pressure Cylinder	200362(803)	Looper Driving Crank Set Screw	204235	Arm Head Position Pin
2022	Plunger Nut (2)	200362(803)	Looper Throw-out Gear Set Screw (2)	204348	Foot Lifter Lever Spring
2102	Lifting Rock Shaft Crank Pin	200364(803)	Spreader Driving Eccentric Counter-balance Set Screw (2)	204365	Needle Thread Tension Releaser Spring
8554	Needle Thread Tension Disc (2)	200364(803)	Spreader Driving Eccentric Set Screw (2)	204925	Looper Driving Crank Oil Hole Cover
	Lifting Rock Shaft Bracket Position Pin (2)	200364(803)	Looper Throw-out Gear Locking	204925	Screw Washer
8582	Arm Position Pin (2)	200364(803)	Plunger Stop Screw Set Screw	206133	Spreader Screw Washer
10148	Looper Thread Tension Spring	200364(803)	Needle Bar Rock Frame Regulating Stud Cap Set Screw	208636	Foot Lifter Lever Rod Hinge Screw Washer
268129	Looper Throw-out Rack Rod	200373(803)	Feed Lifting Link Hinge Pin Set Screw (2)	208636	Feed Dog Shank Screw Washer
268314	Looper Throw-out Rack Rod 268129 with 201553(804)	200373(803)	Foot Lifter Arm Set Screw	214529	Looper Holder Screw Washer
22748	Presser Bar Spring Arm Hinge Screw Washer	200373(803)	Spreader Driving Crank Position Screw	226206	Needle Bar Rock Frame Regulating Stud Spring
32572	Needle Thread Tension Releasing Disc	200376(803)	Needle Bar Crank Position Screw Check Screw	228448	Needle Thread Tension Releasing Pin
50169(809)	Looper Thread Guide (top of Arm)	200380(803)	Feed Bar Hinge Pin Collar Set Screw	236957	Machine Locating Stud (4)
	Bracket Screw (2)	200380(803)	Lifting Eccentric Spacing Collar Set Screw (2)	238089	Thread Lubricator Oil Pad (felt) (3)
50326(803)	Needle Thread Tension Stud	200380(803)	Spreader Holder Set Screw (2)	240245	Needle Thread Tension Releasing Plate Pin
51570(803)	Needle Thread Tension Thumb Nut	200382(833)	Feed Driving Eccentric Adjusting Disc Spring Collar Set Screw (2)	241763	Feed Regulating Stud Retaining Spring
54279	Needle Thread Tension Thread Guide (double)	200386(830)	Feed Driving Rock Shaft Collar Set Screw (4)	241763	Feed Driving Eccentric Friction Plate
59537	Needle Thread Tension Spring Bushing (front)	200386(803)	Feed Lifting Rock Shaft Collar Set Screw (4)	241763	Screw Set Screw Packing (brass) (2)
59538	Needle Thread Tension Spring Bushing (back)	200386(803)	Lifting Rock Shaft Collar Set Screw (2)	241763	Lifting Eccentric Friction Plate
59539	Needle Thread Tension Stud	200386(803)	Looper Throw-out Safety Latch Collar Set Screw (2)	244048	Screw Set Screw Packing (brass) (2)
67425	50326(803) with 51570(803)	200386(803)	Spreader Driving Rock shaft Collar Set Screw (4)	244071	Looper Thread Tension Disc (2)
	Looper Carrier Crank Clamping Stud Washer	200386(803)	Feed Lifting Eccentric Set Screw (2)	244071	Lifting Eccentric Connection Hinge Pin Oil Packing (wick)
67425	Presser Bar Pressure Cylinder Support Stud Nut Lock Washer	200386(803)	Feed Bar Set Screw (2)	244071	Lifting Link Hinge Pin Oil Packing (wick)
	Needle Thread Tension Spring Needle Guard Set Screw	200386(803)	Spreader Driving Crank Set Screw (4)	244071	Looper Throw-out Gear Locking Plunger Spring
131741	Arm Screw (4)	200394(803)	Feed Lifting Eccentric Set Screw (2)	263572	Spreader Driving Rock shaft screw
141220(869)	Arm Head Screw (3)	200400(803)	Feed Bar Set Screw (2)	264709	Send Oil Packing (wick)
200004(805)	Lifting Rock Shaft Bracket Screw (2)	200400(803)	Spreader Driving Crank Set screw		Needle Bar Rock Frame Regulating Stud Cap with 200364(803)
200029(805)	Looper Thread Guide Screw	200400(803)	Lifting Presser Bar Guide Rod Set Screw (lower)	267143	Lifting Lever Needle Bearing (2)
200030(819)	Spreader Bar Bearing Screw (2)	200415(803)	Lifting Crank Set screw	267119	Lifting Rock Shaft Needle Bearing (2)
200035(804)	Feed Dog Shank Screw	200444(803)	Looper Throw-out Gear Locking Plunger Stop Screw	267693	Arm shaft with 268094, 268044, 268264, two each 268214 and 350554(803)
200038(805)	Needle Bar Rock Frame Driving Arm Pinch screw (2)	200562(804)	Looper Thread Tension Bracket Screw (2)	267695	Bed Plate (left)
200040(830)	Arm Shaft Ball Bearing (back) Housing Screw (3)	200571(850)	Face Plate Lock Spring Screw (2)	267696	Bed Plate slide with two 268022 and four 268164(814)
200043(803)	Needle Thread Tension Bracket Screw (2)	200578(850)	Looper Driving Crank Oil Stop Screw	267697	Face Plate with 200352(803), 268133 and two 261416(830)
200047(804)	Bed Plate Screw (8)	200582(803)	Looper Thread Guide (top of arm) Bracket Screw (2)	267610	Lifting Eccentric
200053(819)	Looper Thread Tension Clamp Screw (4)	200630(819)	Needle Bar Rock Frame Thread Guide Screw (2)	267612	Lifting Crank
200054(803)	Foot Lifter Arm Pinch screw	200907(819)	Foot Lifter Crank Stop Screw Stud	267616	Loop Deflector Screw (2)
200056(803)	Lifting Eccentric Connection Crank Pinch Screw (2)	200928(850)	Presser Bar Spring Arm Hinge Screw	267617	Presser Bar Spring Arm Hinge Screw
200061(833)	Feed Driving Rock Shaft Crank Pinch Screw (2)	200947(819)	Looper Thread Tension Stud	267617	Spreader Driving Connection Cap screw (1)
200061(833)	Feed Lifting Rock Shaft Crank Pinch Screw (2)	201022(805)	Needle Thread Tension Releaser Cap Set Screw	267619	Lifting Eccentric Adjusting Disc Spring
200061(833)	Lifting Crank Pinch screw	201052(803)	Lifting Eccentric Connection Hinge Pin Pinch screw	267621	Lifting Eccentric Connection Crank with 201063(805) and two 200392(803)
200064(806)	Looper Thread Take-up Rod Nut Screw	201115(814)	Presser Bar Pressure Cylinder Cap Screw (2)	267622	Lifting Eccentric Flange with 267623, two each 241763, 350467(803), 350477(830) and 350548(803)
200064(804)	Thread Lubricator Screw	201160(805)	Foot Lifter Lever Spring Screw Eye	267643	Feed Driving Eccentric Friction Plate
200066(804)	Lifting Presser Bar Guide Block Pinch Screw	201160(805)	Needle Thread Guide (on Needle Bar Connecting Stud) Set Screw	267623	Needle Bar Rock Frame Driving Eccentric Friction Plate
200069(803)	Needle Bar Connecting Stud Pinch Screw (2)	201254(803)	Arm Shaft Connection Belt Pulley Set Screw (2)	267623	Lifting Eccentric Friction Plate
200074(805)	Arm Side Cover Screw (3)	201254(803)	Bed Shaft Connection Belt Pulley Set Screw (2)	267624	Lifting Eccentric Spacing Collar with two 200380(803)
200075(806)	Feed Regulating Stud Socket Screw (2)	201254(803)	Presser Bar Spring Arm Fulcrum Set Screw (2)	267625	Lifting Lever with two 267643
200078(806)	Lifting Presser Foot Pinch Screw	201254(803)	Feed Lifting Crank Pinch screw	267626	Lifting Lever Hinge Stud
200078(806)	Vibrating Presser Foot Pinch Screw	201254(803)	Foot Lifter Lever Hinge Screw	267627	Lifting Link
200081(803)	Lifting Presser Bar Guide Block Adjusting Screw	201254(803)	Presser Bar Spring Arm Ball Bearing Retainer Screw (2)	267629	Lifting Presser Bar
200082(804)	Needle Thread Guide Screw (2)	201416(806)	Face Plate Hinge Stud Set Screw (2)	267630	Lifting Presser Bar Guide Block with 200066(804) and 200061(803)
200085(803)	Looper Carrier Shaft Bushing (left) Position Plate Screw (2)	201416(803)	Feed Lifting Rock Shaft Crank Position Screw	267631	Lifting Presser Bar Guide Rod
200089(803)	Looper Carrier Crank Hinge Pin Pinch Screw	201471(803)	Looper Throw-out Gear Locking Plunger Screw Bushing	267631	Lifting Presser Bar Lifting Crank with 200254
200095(814)	Needle Bar Connecting Link Cap Washer Screw	201522(805)	Feed Driving Connection Hinge Stud Nut	267632	Lifting Presser Foot with 200078(806)
200098(806)	Looper Throw-out Safety Latch Spring Bracket Screw (2)	201522(805)	Feed Lifting Connection Hinge Stud Nut	267634	Lifting Rock Shaft
200098(806)	Presser Bar Pressure Cylinder Support Retainer Screw (2)	201522(805)	Needle Bar Rock Frame Driving Connection Hinge stud Nut	267635	Lifting Rock Shaft Crank with 200167(805)
200100(803)	Feed Dog Screw (2)	201524(805)	Looper Carrier Crank Clamping Stud Nut	267635	Needle Bar Rock Frame
200110(805)	Throat Plate Screw (3)	201525(805)	Feed Dog Shank Screw Lock Nut	267638	Needle Bar Rock Frame Driving Arm with two 200243(819)
200123(804)	Feed Driving Connection Cap Screw	201525(805)	Foot Lifter Lever Rod Hinge Screw Nut	267639	Needle Bar Rock Frame Driving Eccentric Flange with 267623, two each 241763, 350467(803), 350477(830) and 350548(803)
200123(804)	Needle Bar Rock Frame Driving Connection Cap Screw	201537(814)	Feed Dog Shank Adjusting Screw Lock Nut	267644	Presser Bar Spring Arm Fork
200125(833)	Needle Set Screw	201553(804)	Looper Throw-out Rack Rod Thumb Nut	267645	Presser Bar Spring Arm Fork Lock Washer (inven)
200154(819)	Bed Plate Slide Spring Screw (4)	201572(814)	Looper Thread Tension Thumb Nut	267650	Presser Bar Pressure Cylinder Support Retainer
200167(805)	Lifting Link Hinge Pin Set Screw (4)	201620(804)	Looper Throw-out Gear Locking Plunger Thumb Nut	267653	Presser Bar Pressure Cylinder Plunger Bushing
200174(804)	Needle Bar Guiding Feet Holder Screw (2)	201622(819)	Presser Bar Spring Arm Hinge Screw Nut	267653	Thread Lubricator with three 268157
200305(814)	Looper Driving Crank Oil Hole Cover Screw	201734(805)	Spreader Driving Rock shaft screw Stud Nut	267657	Vibrating Presser Bar
200327(803)	Machine Pulley Set Screw	201746(814)	Presser Bar Pressure Cylinder Support Stud Nut (3)	267658	Vibrating Presser Bar Hinge Stud
200328(803)	Machine Pulley Position Screw	202005	Arm Screw Washer (4)	267659	Vibrating Presser Foot with 200078(806)
200337(803)	Needle Bar Rock Frame Regulating Stud Sleeve Set Screw	202159	Arm Shaft Connection Belt Pulley Spring Flange (2)	267661	Throat Plate
200344(830)	Looper Driving Crank Position Screw (2)	202235	Needle Bar Connecting Stud Oil Packing (wick)	267664	Feed Dog, 46 needle hole, with 267625 and two 268047(819), for 267625
200348(803)	Needle Bar Crank Set Screw	202574	Feed Bar Hinge Pin Collar with 200360(803)	267665	Loop Deflector
200351(830)	Lifting Presser Bar Guide Rod Set Screw (upper)			267667	Arm Side Cover
200353(802)	Face Plate Hinge Stud Set Screw (long)				
200354(802)	Feed Driving Rock Frame Position Screw				
200354(802)	Looper Carrier Shaft Bushing Position Screw (1)				
200354(802)	Needle Bar Crank Position Screw				
200362(803)	Feed Driving Rock Frame Set Screw				
200362(803)	Lifting Lever Hinge Stud Set Screw (2)				
200362(803)	Looper Carrier Shaft Bushing Set Screw (2)				

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
267702	Foot Lifter Arm with 200058(803) and 200373(803)	268069	Feed Driving Rock Frame with 200354(803) and 200362(803)	268258	Looper Carrier Crank Hinge Pin Oil Packing (wick)
267704	Foot Lifter Lever Rod with 248423	268070	Feed Driving Rock Shaft	268258	Needle Bar Rock Frame Driving Connection Hinge Stud Oil Packing (wick)
267705	Needle Bar Crank with 200346(803), 200354(803) and 200376(803)	268071	Feed Driving Rock Shaft Needle Bearing (2)	268261	Bed Shaft Connection Belt Pulley 268028 with 268024
267706	Needle Bar Crank 267705 with 268005	268071	Feed Lifting Rock Shaft Needle Bearing (2)	268263	Needle Thread Tension complete, Nos. 32572, 59537, 59538, 59539, 131741 and two 2102
267707	Needle Thread Tension Releasing Plate (adjustable)	268072	Feeder Driving Rock Shaft Needle Bearing (2)	268264	Arm Shaft Oil Control Rod (wood)
267708	Presser Bar Pressure Cylinder with 267653	268072	Feed Driving Rock Shaft Collar with two 200386(830) (2)	268265	Bed Shaft Oil Control Rod (wood)
267709	Presser Bar Pressure Cylinder Cap	268072	Feed Lifting Rock Shaft Collar with two 200386(803) (2)	268270	Arm Shaft Connection Belt (reinforced neoprene)
267710	Presser Bar Pressure Cylinder Plunger	268072	Lifting Rock Shaft Collar with two 200386(803)	268277	Looper Driving Crank with 200362(803), 200573(804) and two 200344(830)
267711	Presser Bar Pressure Cylinder Plunger Disc	268072	Feeder Driving Rock Shaft Collar with two 200386(803) (2)	268278	Needle Bar Oiling Flt Holder (2)
267712	Presser Bar Pressure Cylinder Plunger Washer (leather)	268073	Feed Driving Rock Shaft Crank with two 200061(833)	268307	Looper Carrier Crank with 200059(803)
267713	Presser Bar Pressure Cylinder Plunger Washer (steel)	268074	Feed Lifting Connection	268308	Looper Carrier Crank Clamping Stud
267714	Presser Bar Pressure Cylinder Support	268075	Feed Lifting Crank with 200373(803) and 201256(830)	268310	Needle Guard
267715	Presser Bar Pressure Cylinder complete, Nos. 67425, 267644, 267645, 267708, 267709, 267710, 267711, 267712, 267713, 267716, 350579(819), 931758, 994778, two each 1517(803), 201110(819) and three 201746(819)	268077	Feed Lifting Eccentric Lubricating Pad (wood)	268312	Needle Thread Guide (on Arm Head)
267716	Presser Bar Spring	268078	Feed Lifting Link	268313	Looper Throw-out Gear Locking Plunger Handle
267718	Presser Bar Spring Arm Ball Bearing Retainer	268079	Feed Lifting Link Hinge Pin with 268258 (2)	268315	Feed Driving Flange with 267623, two each 241763, 350467(803), 150477(830) and 350548(803)
267719	Presser Bar Spring Arm Fulcrum	268080	Feed Lifting Rock Shaft	268316	Feed Dog Shank with 201517(819) and 350522(803)
267736	Lifting Eccentric Connection	268081	Feed Regulating Stud	268330	Face Plate Hinge Stud (2)
267737	Lifting Eccentric Connection 267736 with 271055	268082	Feed Regulating Stud Socket	268331	Looper Thread Tension Bracket
267738	Presser Bar Spring Arm	268083	Foot Lifter Lever with 268089	268332	Looper Thread Tension complete, Nos. 10148, 200987(819), 201573(819) and two 244048
268004	Arm Shaft Ball Bearing (back) Housing	268084	Looper Carrier Shaft Bushing (left)	268333	Looper Thread Tension Thread Guide
268005	Arm Shaft Ball Bearing (front)	268085	Position Plate	268367	Looper Carrier
268006	Arm Shaft Connection Belt Pulley with two each 201354(803) and 202253	268086	Looper Carrier Shaft Bushing (right)	268368	Looper Carrier 268367 with two 268084
268008	Arm Shaft Oil Slinger with 350171(803)	268090	Looper Carrier Needle Bearing (2)	268369	Looper with 141220(804)
268022	Arm Shaft Oil Stop Ball Spring (front)	268092	Looper Driving Crank Oil Hole Cover	268371	Looper and Needle Guard complete, Nos. 268119 and 268369
268024	Arm Shaft Ball Bearing (back)	268111	Looper Thread Guide (top of Arm) Bracket	268373	Looper Thread Guide (on side of looper) for all gauges from 3/16 to 2 inches
268024	Bed Shaft Ball Bearing	268121	Looper Thread Tension Bracket Spacing Collar (2)	268402	Bed Plate (right)
268028	Bed Shaft Connection Belt Pulley with two 201354(803)	268121	Needle Thread Tension Bracket Spacing Collar (2)	268403	Looper Thread Guide (top of Arm)
268029	Bed Shaft Needle Bearing (2)	268123	Looper Thread Tube with two 268125	268406	Looper Thread Guide (top of Arm) Bracket 268111 with 268405 and two 351494(830)
268029	Needle Bar Rock Frame Needle Bearing (2)	268124	Looper Thread Tube Thread Bushing (2)	268512	Needle Thread Guide (on Needle Bar Connecting Stud)
268032	Face Plate Lock Spring	268125	Looper Thread Tube Thread Bushing (2)	268513	Needle Thread Guide (on side of Arm) (2)
268033	Face Plate Lock Stud	268126	Looper Throw-out Gear with two 200362(803)	268602	Looper Holder with two 350476(803)
268034	Feed Bar with 200373(803) and two 200403(830)	268127	Looper Throw-out Gear Locking Plunger	268603	Feeder with 268102
268035	Feed Bar Hinge Pin	268131	Looper Throw-out Safety Latch	268606	Feed Regulating Stud Spring
268044	Arm Shaft Oil Stop Ball Spring (rear)	268132	Looper Throw-out Safety Latch Spring	270200	Needle Bar Connecting Link Needle Bearing (2)
268044	Bed Shaft Oil Stop Ball Spring	268133	Looper Throw-out Safety Latch Spring Bracket	271055	Lifting Eccentric Connection Needle Bearing
268045	Spreader Driving Eccentric with two 200364(803)	268603	Needle Bar	270202	Presser Bar Spring Arm Ball Bearing
268046	Spreader Driving Eccentric Counter-balance with two 200364(803)	268134	Needle Bar Connecting Link Cap Washer	264423	Foot Lifter Lever Rod Center Pin
268047	Feed Lifting Eccentric with 268077 and two 268094(803)	268141	Needle Bar Connecting Stud with 201354, 201355, 201356 and two 200064(803)	340400(803)	Spreader Driving Rock Shaft Screw Stud with 261572
268048	Machine Pulley (aluminum alloy cast-iron) for V-belt (outside diameter of belt groove 2.9 inches) with 200327(803) and 200328(803)	268144	Needle Bar Rock Frame Regulating Stud	350149(803)	Spreader screw
268049	Machine Pulley 268048 with 268024	268149	Needle Bar Rock Frame Regulating Stud Sleeve	350171(803)	Arm Shaft Oil Slinger Set screw
268051	Looper Thread Guide	268150	Needle Bar Rock Frame Regulating Stud complete, Nos. 214526, 264734, 268148 and 268149	350267(803)	Looper Holder screw
268052	Looper Thread Take-up Rod	268152	Feeder Point	350467(803)	Feed Driving Flange Set screw (2)
268053	Spreader Driving Rock Shaft with 201354(803)	268157	Needle Thread Tension Bracket	350467(803)	Foot Lifter Lever (back) Spring Screw
268054	Bed Shaft with 268044, 268214, 268265 and 350534(803)	268158	Needle Thread Tension Releaser	350467(803)	Lifting Eccentric Flange Set screw (2)
268056	Needle Bar Connecting Link 268055 with two 270200	268159	Needle Thread Tension Releaser Cap with 211052(833)	350467(803)	Needle Bar Rock Frame Driving Eccentric Flange Set screw (2)
268060	Feeder Driving Connection	268181	Spreader Bar	350468(830)	Looper Thread Guide (on bed at looper) screw
268060	Needle Bar Rock Frame Driving Connection	268184	Spreader Bar Bearing	350477(830)	Feed Driving Eccentric Friction Plate screw Set screw (2)
268061	Feed Driving Connection Hinge Stud with 268063	268185	Spreader Holder with two 200380(803)	350477(830)	Lifting Eccentric Friction Plate screw Set screw (2)
268061	Needle Bar Rock Frame Driving Connection 268060 with 268063	268186	Spreader Driving Connection with two 351111 (803)	350477(830)	Needle Bar Rock Frame Driving Eccentric Friction Plate screw Set screw (2)
268062	Feed Driving Connection Hinge Stud with 268253	268187	Feeder Driving Crank with 200373(803) and 200403(830)	350478(803)	Looper Set screw
268062	Feed Lifting Connection Hinge Stud with 268253	268190	Feeder Driving Pin	350478(803)	Looper Adjusting screw
268062	Needle Bar Rock Frame Driving Connection Hinge Stud with 268253	268197	Face Plate Lock Spring Plate	350524(819)	Foot Lifter Lever Rod Hinge Screw
268063	Feed Driving Connection Needle Bearing	268198	Feed Lifting Rock Shaft Crank with 201418(823) and two 200961(833)	350534(803)	Arm Shaft Oil Stop Ball Screw (2)
268064	Feed Driving Eccentric	268199	Looper Throw-out Safety Latch Collar with two 200380(830)	350534(803)	Bed Shaft Oil Stop Ball Screw
268064	Needle Bar Rock Frame Driving Eccentric	268208	Looper Carrier Crank Hinge Pin with 268253	350548(803)	Feed Driving Eccentric Friction Plate screw (2)
268065	Feed Driving Eccentric Adjusting Disc	268214	Arm Shaft Oil Stop Ball 3/32 in. diam. (2)	350548(803)	Lifting Eccentric Friction Plate screw (2)
268065	Lifting Eccentric Adjusting Disc	268214	Bed Shaft Oil Stop Ball	350548(803)	Needle Bar Rock Frame Driving Eccentric Friction Plate screw (2)
268065	Needle Bar Rock Frame Driving Eccentric Adjusting Disc	268216	Looper Driving Connection 268098 with 268111	350552(803)	Feed Dog Shank Adjusting screw
268066	Feed Driving Eccentric Adjusting Disc Spring	268219	Needle Bar Rock Frame Thread Guide	350573(803)	Presser Bar Pressure Cylinder Support Stud
268067	Feed Driving Eccentric Adjusting Disc Spring Collar with two 200382(853)	268220	Feeder Driving Eccentric Thrust Washer (2)	351876	Spreader Driving Rock Shaft Screw Stud Ball Roller
		268233	Feeder Driving Connection 268186 with 268063 and 351876	23184	Presser Bar Pressure Cylinder Hose Connection Washer
		268258	Feed Driving Connection Hinge Stud Oil Packing (wick)	044778	Presser Bar Pressure Cylinder Hose Connection
		268258	Feed Lifting Connection Hinge Stud Oil Packing (wick)		
		268258	Feed Lifting Link Hinge Pin Oil Packing (wick) (2)		
		268258	Lifting Presser Bar Lifting Crank Oil Packing (wick)		

ACCESSORIES

PART NO.	DESCRIPTION
994719	Air Compressor for Electric Transmitters Nos. 547 and 569
995475	Air Filter
160137	Air Hose
265307	Bed Hinge Connection (2)
350598	Bed Hinge Connection Screw (4)
228731	Drip Pan
200019	Drip Pan Screw (4)
232365	Foot Lifter Treadle Chain 41-1/2 in. long
268340	Looper Threading Wire
228452	Machine Base Oil Drain Jar complete
228444	Machine Cushion (neoprene)
228733	Machine Rest (left)
228734	Machine Rest (right)
41400	Machine Rest Pin
Cat. No.	
4112	Needles (52 x 59) Size 23 (6)
267722	Presser Bar Pressure Control Valve complete
228491	Pressure Oiler
228745	Thread Unwinder complete
120341	Tweezers
21887	Wrench